# **SEAL EASY**Hose, Tube and Pipe Sealing Systems



Ultra Clean Technologies offers innovative and economical solutions to protect cleaned hoses, tubes and pipes. The **Clean Seal System** heat-shrinks a **Clean Seal Capsule** tightly around the end of a hose assembly. Seal a single hose, or multiple hoses simultaneously! Just sixteen size capsules needed for most applications. Shorter capsules available to accommodate angle/elbow (ie: 45° and 90°) fittings.

Heat Shrink Machine
Clean Seal Capsules
Heat Shrink Gun, Heat Diffusers, and Flexible Stand
Capsule Dispenser Stand

### Clean Seal System

The Clean Seal System utilizes heat shrink technology to encapsulate the end of a hose or tube assembly with a Clean Seal Capsule, eliminating re-contamination that is problematic with traditional capping and plugging methods. Re-contamination occurs when ill-fitting caps and plugs are forced onto assemblies, causing plastic particles to shear off into the hose or tube. Clean Seal System leaves your assemblies tightly sealed and 100% contamination free, and provides an easier, less costly, and more effective solution than traditional capping methods. You'll never have to deal with an excessive cap and plug inventory again.

- Preserves cleanliness.
- Easy to use heat shrink machine or heat shrink gun for low or high volume production.
- Fast and easy capsule installation.
- Universal, clean fit up to 3" (80mm).
- Seals straight and elbow couplings shorter capsules available for angled/ elbow (i.e.: 45° and 90°) fittings.
- Eliminates cap inventory hassles.



# UC-CSC-2023 through UC-CSC-8060 Clean Seal Capsules

- Just 16 capsule sizes needed for all assemblies.
- Durable and secure.
- Quick, clean application.
- Blue color for quick and easy identification of sealed hoses.
- Easy, clean pull-tab capsule removal.
- No particulates or sticky residue left behind.
- Sold in bulk cartons or packaged quantities.
- Shipped pre-stacked to ensure cleanliness on inside.
- Private label options available.



Clean Seal Capsules stack neatly for efficient shipping and storing!

#### To Apply

- 1. Choose the closest fit capsule and place onto assembly end.
- 2. Use the heat shrink machine or gun to apply heat.

#### To Remove

- 1. Grip the black pull tab.
- 2. Rip the pull tab upwards.
- 3. Slip the Clean Seal Capsule off the assembly.



Just seconds to apply and remove!

### **UC-CSS-230V-G2 Heat Shrink Machine**



Pictured: UC-CSS-230V-HG-G2 unitwith heat guard.

- Seals single OR multiple hose or tube assemblies.
- Uses Clean Seal Capsules from 3/4" I.D. (20mm) through 3" I.D. (80mm) for sealing and thread protection of hose and tube ends from -4 (1/4") through -32 (2").
- White plunger provides surface to hold Clean Seal Capsule in place on fitting, including angle/ elbow (ie: 45° and 90°) fittings, and aids even heat distribution for a perfect shrink-fit..
- 230V single-phase AC power at 50/60Hz draws < 5
- Customer supplies L6-15 NEMA twist lock receptacle.
- ON/Off rocker switch illuminates green when "on."
- Hot Air Blower Timer sets in 1-minute increments.
- When on, Timer Light illuminates white.
- 24/7 operating capacity.
- Pre-filtered air prohibits airborne contamination.
- Heat side of machine is fully insulated.
- Brushless internal heat source for industrial applications.

### **UC-HL1920E Heat Shrink Gun**



#### Available in North America and Europe only

- Variable-temperature electronic heat gun with electronic thermocouple control for flexible use and maximum reliability.
- Duratherm heating element ensures long life and even heat with a temperature range of 120°F (49°C) to 1100°F (593°C) and a built-in cool down switch.
- 120V AC power, draws 1500 watts, and can produce 17.6CFM. European model operates on 240V AC power and comes with european plug.
- Capable of sealing multiple hoses simultaneously.
- Various nozzle attachments included for applications other than shrinking of Clean Seal Capsules.

#### **UC-1920-STAND**

Available in North America and Europe only



- Vacuum pump stand is for hands-free operation of the UC-HL1920E heat gun.
- Adjustable to almost any position.
- Makes your job of shrinking capsules quicker and easier!

# UC-1.5HD & UC-2.0HD Heat Diffusers



- Heat Diffusers enable a 360° even hot air flow to shrik the Clean Seal Capsules.
- Intended for heat guns that have a 1½"
   (38mm) and 2" (50mm) O.D. on the
  heating element.
- UC-2.0HD is made of 304 Stainless Steel for a long contamination-free life.
- UC-1.5HD works perfectly with the UC-HL1920 Heat Gun.

## **Available Kits (3)**

Available in North America only

1. UC-HL1920HK: Hardware-only kit that includes portable heat shrink gun, flexible stand, 95mm diffuser with 1½" connection.





- 2. UC-HL1920SK: Hardware & Capsules Starter Kit that includes capsules listed on Clean Seal System Parts List on following pages.
- 3. UC-HL1920SK-2: Hardware & Capsules Starter Kit for applications up to 2" ID that includes capsules listed on Clean Seal System Parts List on following pages.



# **UC-CDS Capsule Dispenser Stand**

#### Easily stores and dispenses Clean Seal Capsules!







 Capsule identifier (size/part number) labels provided for dispenser tubes for easy identification, loading and re-ordering.



Grommet and lanyard for pull-wand included!

- Laminated Clean Seal Capsule chart included.
- Unique magnetic disc and removal wand system assists in gently dispensing the first capsule from every newly inserted Clean Seal Capsule stick.



 Easel-like design enables placement on a bench or flat surface, or mounted to a wall.

| UC-CDS Capsule Dispenser Stand |   |  |  |  |  |  |  |  |
|--------------------------------|---|--|--|--|--|--|--|--|
| Part #                         | Description   |  |  |  |  |  |  |  |
| UC-CDS Includes:               |   |  |  |  |  |  |  |  |
| UC-CDS                         | Capsule Dispenser Stand w/magnetic strip  |  |  |  |  |  |  |  |
| UC-CD-Wand                     | Capsule Dispenser Removal Wand  |  |  |  |  |  |  |  |
| UC-CD-SC                       | Laminated Clean Seal Capsule Sizing Chart w/Grommet   |  |  |  |  |  |  |  |
| UC-CD-LNYD                     | Laminated Clean Seal Capsule Sizing Chart w/Lanyard   |  |  |  |  |  |  |  |
| Dispensers                     |   |  |  |  |  |  |  |  |
| UC-CD-1.5                      | DISPENSER FOR: UC-CSC-2023, UC-CSC-2030, UC-CSC-2224, UC-CSC-2527, UC-CSC-2540, UC-CSC-2840, UC-CSC-3133, & UC-CSC-3140 |  |  |  |  |  |  |  |
| UC-CD-2.5                      | DISPENSER FOR: UC-CSC-3440, UC-CSC-3840, UC-CSC-4345, UC-CSC-4650   |  |  |  |  |  |  |  |
| UC-CD-3.0                      | DISPENSER FOR: UC-CSC-5260, UC-CSC-5860, UC-CSC-676   |  |  |  |  |  |  |  |
| Kit                            |   |  |  |  |  |  |  |  |
| UC-CD-DK                       | Capsule Dispenser Kit includes stand with magnetic strip, 3 small, 1 medium, and 1 large dispenser tube.                |  |  |  |  |  |  |  |

• The full size range of Clean Seal Capsules is accommodated by just three sizes of transparent dispenser tubes (UC-CD-1.5, UC-CD-2.5, & UC-CD-3.0). Each capsule size requires a separate dispenser tube.

# **Clean Seal System Parts List**

#### HEAT SHRINK SYSTEMS AND ACCESSORIES

| PART NUMBER#                   | DESCRIPTION  |  |  |  |  |  |  |  |
|--------------------------------|--|--|--|--|--|--|--|--|
| HEAT SHRINK MACHINE            |  |  |  |  |  |  |  |  |
| UC-CSS-230V-G2                 | PRODUCTION HEAT SHRINK MACHINE with TIMER  |  |  |  |  |  |  |  |
| UC-CSS-230V-HG-G2              | PRODUCTION HEAT SHRINK MACHINE with TIMER and HEAT GUARD   |  |  |  |  |  |  |  |
| HEAT SHRINK GUNS & ACCESSORIES |  |  |  |  |  |  |  |  |
| UC-HL1920E                     | HL1920E ELECTRIC HEAT GUN  |  |  |  |  |  |  |  |
| UC-1920-STAND                  | FLEX VACUUM PUMP STAND   |  |  |  |  |  |  |  |
| UC-1.5HD                       | 95MM DIFFUSER FOR 1½" CONNECTION   |  |  |  |  |  |  |  |
| UC-2.0HD                       | 2.0HD 95MM DIFFUSER FOR 2" CONNECTION  |  |  |  |  |  |  |  |
| CLEAN SEAL KITS                | CLEAN SEAL KITS  |  |  |  |  |  |  |  |
| UC-HL1920HK<br>(Hardware Kit)  | PORTABLE HEAT SHRINK GUN WITH CASE (UC-HL1920E), FLEXIBLE STAND (UC-HG-STAND), 95 mm DIFFUSER WITH $1\frac{1}{2}$ " CONNECTION (UC-1.5HD)  |  |  |  |  |  |  |  |
| UC-HL1920SK<br>(Starter Kit)   | INCLUDES ALL COMPONENTS OF UC-HL1920HK KIT, PLUS 1 PACKAGE OF EACH CAPSULE SIZE UC-CSC-2030P, UC-CSC-2540P, UC-CSC-2840P, UC-CSC-3140P, UC-CSC-3440P, UC-CSC-3840P, UC-CSC-4650P |  |  |  |  |  |  |  |
| UC-HL1920SK-2                  | INCLUDES ALL COMPONENTS OF UC-HL1920HK and UC-HL1920SK KITS, PLUS 1 PACKAGE OF EACH CAPSULE SIZE UC-CSC-5260P, UC-CSC-6760P, UC-CSC-8060P  |  |  |  |  |  |  |  |

#### CLEAN SEAL CAPSULES \*Shorter length capsules are recommended for elbow/angled fittings (i.e. 45° and 90°).

|                       | PACKA                       | GED                       | BULK                    |                       | SIZING  |                               |                                   | *FITTING |       |
|-----------------------|-----------------------------|---------------------------|-------------------------|-----------------------|---|-------------------------------|-----------------------------------|----------|-------|
|                       | PART<br>NUMBER#<br>PACKAGED | CARTON<br>QTY<br>PACKAGED | PART<br>NUMBER#<br>BULK | CARTON<br>QTY<br>BULK | CAPSULE<br>SIZE<br>Inside Diameter<br>x Length<br>in mm | HEX SIZES<br>COVERED<br>in mm | HEX SIZES<br>COVERED<br>in inches | STRAIGHT | ELBOW |
|                       | UC-CSC-2023P                | 810                       | UC-CSC-2023B            | 23,400                | 20 X 23   | 12mm to 18mm                  | .47" to .71"                      |          | Χ     |
| OSK.                  | UC-CSC-2030P                | 810                       | UC-CSC-2030B            | 23,400                | 20 X 30   | 12mm to 18mm                  | .47" to .71"                      | Χ        |       |
| UC-HL1920SK           | UC-CSC-2224P                | 810                       | UC-CSC-2224B            | 22,500                | 22 X 24   | 16mm to 21mm                  | .63" to .82"                      |          | Χ     |
| UC-H                  | UC-CSC-2527P                | 800                       | UC-CSC-2527B            | 17,600                | 25 X 27   | 18mm to 23mm                  | .71" to .91"                      |          | Χ     |
|                       | UC-CSC-2540P                | 800                       | UC-CSC-2540B            | 17,600                | 25 X 40   | 18mm to 23mm                  | .71" to .91"                      | Χ        |       |
| ıded i                | UC-CSC-2840P                | 720                       | UC-CSC-2840B            | 15,200                | 28 X 40   | 22mm to 26mm                  | .87" to 1.02"                     | Χ        |       |
| sizes included in kit | UC-CSC-3133P                | 640                       | UC-CSC-3133B            | 12,240                | 31 X 33   | 24mm to 29mm                  | .94" to 1.14"                     |          | Χ     |
| capsule size          | UC-CSC-3140P                | 640                       | UC-CSC-3140B            | 12,240                | 31 X 40   | 24mm to 29mm                  | .95" to 1.14"                     | Χ        |       |
|                       | UC-CSC-3440P                | 640                       | UC-CSC-3440B            | 10,240                | 34 X 40   | 27mm to 32mm                  | 1.07" to 1.26"                    | Χ        |       |
|                       | UC-CSC-3840P                | 560                       | UC-CSC-3840B            | 7,800                 | 38 X 40   | 30mm to 36mm                  | 1.19" to 1.42"                    | Χ        | Χ     |
| indicates             | UC-CSC-4345P                | 480                       | UC-CSC-4345B            | 6,240                 | 43 X 45   | 32mm to 41mm                  | 1.26" to 1.61"                    | Χ        | Χ     |
| area                  | UC-CSC-4650P                | 480                       | UC-CSC-4650B            | 5,760                 | 46 X 50   | 34mm to 44mm                  | 1.34" to 1.73"                    | Χ        | Χ     |
| Grey                  | UC-CSC-5260P                | 400                       | UC-CSC-5260B            | 4,400                 | 52 X 60   | 41mm to 50mm                  | 1.62" to 1.97"                    | Χ        | Χ     |
|                       | UC-CSC-5860P                | 400                       | UC-CSC-5860B            | 3,600                 | 58 X 60   | 49mm to 56mm                  | 1.93" to 2.20"                    | Χ        | Χ     |
|                       | UC-CSC-6760P                | 320                       | UC-CSC-6760B            | 2,560                 | 67 X 60   | 55mm to 65mm                  | 2.16" to 2.56"                    | Χ        | Χ     |
|                       | UC-CSC-8060P                | 420                       | UC-CSC-8060B            | 1,736                 | 80 X 60   | 64mm to 78mm                  | 2.52" to 3.07"                    | Х        | Χ     |